

INSTALLATION STEPS:

1. IDENTIFY THE WALL FIXTURE AND LOCATION OF INSTALLATION OF THE T-BLOCK AND BETWEEN THE STUDS
2. AFFIX T-BLOCK IN CHOSEN LOCATION BEHIND THE CENTER OF THE WALL FIXTURE ATTACHMENT POINTS
3. CENTER T-BLOCK BETWEEN THE STUDS BEFORE SCREWING

ENSURE T-BLOCKING IS INSTALLED WITHOUT OVERLAPPING

T-BLOCKING

STUD

STUD
T-BLOCKING

AFFIX T-BLOCKING WITH STUDS USING FOUR (4) SCREWS

END VIEW

T-BLOCKING



Telling® Industries, LLC.

THE LEADER IN METAL
FRAMING INNOVATION

www.BuildStrong.com
866- FRAME-TI (372-6384)

This drawing serves as a reference only and should not substitute the expertise of a qualified architect or engineer. It is intended to aid in the development of cold-formed steel framing construction details. A thorough evaluation and approval by a qualified architect or engineer are required.